

Technical information

Light Curtain Type LA



Status: 2011-04-27

Subject to change without notice. No responsibility is taken for the correctness of this information.

Your suggestions for corrections or improvements are welcome!

Features

- No separate control unit is needed. The device can be directly connected to 24 V DC.
- 2 short-circuit-proof PNP-outputs, NPNoutputs optionally
- Functions and parameters configurable via PC interface.
- Easy-Run: full configuration settings from factory.
- Automatic range setting during calibration cycle
- Diagonal beams analysis for enhanced monitoring resolution.

DUOmetric AG

Weberstr. 8

86836 Lagerlechfeld /Graben

Tel: +49-8232-95979-0 Fax: +49-8232-95979-29

www.duometric.de

E-Mail: support@duometric.de



Table of content


reatures	1
Table of content	
The bars and mechanical design	3
Functions	4
Signal output	4
Switching Threshold	4
Usage	4
Output assignment	4
Output assignment "normal"	4
Output assignment "inverted"	4
Output assignment "inverted without warning"	5
OutDelay	5
Beam variations	
Recommendations:	6
Contamination alarm	
Recommendations:	6
TopBlankable	7
Beam Blanking	7
Recommendations:	
Syncbeam – Synchronisation beam	7
Recommendations:	
Areas	7
Recommendations:	7
NOFDARK	8
Configuration values	9
Recommendation	
Calibration Sequence	. 10
Recommendations:	. 10
Flashing codes during the calibration cycle	. 10
LED Indicators / Error Diagnosis	. 11
Receiver bar	
Transmitter bar	. 11
Interfaces / Outputs	. 12
M8 connector	
Installation / Initial Operation	
Conformity	
Technical Data	
PC-Interface	. 14
Ordering Key and Example	
Key:	
Example	
Accessories	



The bars and mechanical design

A wide choice of beam spacing and attachment options (mechanical) is available. Please refer to separate light curtain bar information sheet:

Information sheet: light curtain bars





Functions

Signal output

You can configure the light curtain to be light or dark switching via the *output function* parameter.

	light	dark
Free beams	active	inactive
interrupted beams	inactive	active

Switching Threshold

During the calibration sequence the signal intensity of each (parallel) beam is measured and permanently stored. By multiplying with the relative switching threshold (percentage of the relative threshold) the absolute threshold for each beam is determined.

In order to have the system react to small signal reductions a higher switching threshold has to be adjusted. The threshold shall not exceed 179 (equivalent to \sim 70%).

Usage

Automatic threshold detection
 Detection of transparent objects
 Reduced beam deflection influence

=> RelThreshold = 0
=> high threshold
=> high threshold

Output assignment

The light curtain has two outputs (wires black and yellow).

The Output functions can be set via the parameter *Output assignment*.

Output assignment "normal"

Output	Wire	Function	Description	
Out 1	Yellow	Signal out	light or dark switching	
Out 2	Black	Warning out	Active during disruption	
	Exception -> Start second range ≠ "0"			
Out 1	Yellow	Area 1	light or dark switching	
Out 2	Black	Area 2	light or dark switching	

Output assignment "inverted"

Functions like "normal" but with switched outputs

Output	Wire	Function	Description	
Out 1	Yellow	Warning out		
Out 2 Black Signal out light or dark switching				
Exception -> Start second range ≠ "0"				



Out 1	Yellow	Area 2	light or dark switching
Out 2	Black	Area 1	light or dark switching

Output assignment "inverted without warning"

Out 1 is without function.

Out 2 is used as Signal out on black wire

Output	Wire	Function	Description	
Out 1	Yellow	-	No function	
Out 2	Black	Signal out	light or dark switching	
	Exception -> Start second range ≠ "0"			
Out 1	Yellow	- No function		
Out 2	Black	Area 1	light or dark switching	

Output assignment "antivalent "

Out 1 is as Signal out on yellow wire Out 2 is active when Out 1 is inactive.

OutDelay

This configuration value delays the status change of switching outputs by the set value in milliseconds (ms). Maximum delay value is 255 ms.



Beam variations

Parameter	Diagonal = 0	Diagonal = 1	Diagonal = 4
Description	diagonal beams off	diagonal beams on	Multiple beam crossings
Number of beams	n	2n-1	5n-6
Max beam number (n)	128	64	26
Drawing			



Recommendations:

- o After changing this parameter run a calibration cycle.
- The cycle time increases with the number of beams.
- A total of 128 logical beams is supported.

Contamination alarm

If the beam brightness remains under a certain threshold (**weak signal threshold**) for a specific duration (**weak signal delay**), the light curtain signals a "simple error". Remedy:

- Clean the beam output.
 Attention: do not damage the front foil. Do not use caustic cleaning agents.
- Align the bars and recalibrate.



Recommendations:

Set the **weak signal threshold** parameter to "0" in order to switch off the contamination alarm.

TopBlankable

When turning on the device interrupted beams and the bar ends can be blanked out permanently.. *TopBlankable* defines, how many consecutive beams are blanked out.

This function was specifically implemented for elevator systems.

Beam Blanking

Permanently interrupted beams can be blanked automatically. Which identical beams can be blanked is adjusted with the **Max.autoblanked** parameter.

Max.autoblanked	Automatic Blanking
0	None
1	each 2. identical beam
2	each 3. identical beam

Defective beams are not considered in the analysis. The parameter *Maxdefect* defines the number of ignored beams. A serious error is signaled should the number of defective beams exceed the value of *Maxdefect*.

Blanked out beams are not added to Maxdefect.



Recommendations:

- Use the section Beam Configuration on the right side of the DUO-Konfapplication window in order to manually blank out beams. Select there which receiver element shall be blanked out.
- The Syncbeam must always stay active!

Syncbeam - Synchronisation beam

The **Syncbeam** parameter defines whether the first (near the connectivity point) or the last beam is used for the optical synchronisation.



Recommendations:

- Transmitter and receiver have to be set to the same value.
- The Syncbeam cannot be blanked.
- o Interruption of the Syncbeam is signal on both sections.

Areas

Parameter **Start second area** separates the light curtain into two areas. The status of the areas is signaled at outputs OUT 1 and OUT 2.



Recommendations:

- Switching ranges for *Diagonal* ≠ 0 (=> diagonal beams on) overlap.
- Interruption of the Syncbeam is signaled in both areas.
- Areas can be configured to be light or dark switching.

DUOmetric

Light Curtain Type LAII

NOFDARK

Defines the threshold after which number of interrupted beams the outputs are switched (separately for both areas).

Example: NofDark1 = '5'

=> Output of areas 1 switches after 5 interrupted beams in section 1.

Special: "Start second area"= '1'

Both NofDark-values relate to the entire monitoring range.

After reaching the corresponding number id interrupts the corresponding output is switched.



Configuration values

	Standard value	Description
First Beam	1	value always equals 1
Last Beam ¹	XX	value is system dependent
Output function	\rightarrow	Light switching Dark switching
Output assignment	→	normal inverted inverted without warning antivalent
Diagonal	→	0 = diagonal beams off 1 = diagonal beams on 24 = multiple beam crossings
Relative Threshold	84	84 equals 33% (256 equals 100%) 0 = automatic theshold adjustment activ.
Maxdefect	1	Max. number of allowed defective beams
Delay for Autoblanking	60	Time in seconds until a beam interruption can be blanked
Max. Autoblanked	0	Number of consecutive identical beams available for blanking
Start for second area	0	Beam number defining the start oft he second section. Only recommended for "Diagonal = 0"!
Syncbeam	\rightarrow	first = synchronisation via first beam last = synchronisation via last beam
NofDark1	1	Minimum number of interrupted beams defining an interruption. (Area 1)
NofDark2	1	Minimum number of interrupted beams defining an interruption. (Area 2)
OutDelay	0	Duration in ms between output state changes. (range: 0 – 255 ms)
TopBlankable	0	number (1,2 or 3) of beams that can be blanked consecutively during power-up.
Weak signal threshold	147	Threshold for contamination warning. equals 57% (Wert x 256)
Weak signal delay	60	Time in seconds after which a contamination is signaled
AutoCalDelay		



Recommendation

 Configuration value "Syncbeam" must be identical for Transmitter and Reciever for the light curtain to work properly.

¹ Only the value of physically present beams can be adjusted. A incorrect value can result in improper functionality.



Calibration Sequence

- Place yellow wire on +24 V DC during activation.
 self-calibration (other flashing signals as those in normal mode).
- 2. Both LED of the receiver bar illuminate steady => self-calibration is completed without an error.
- 3. Remove yellow wire as long as LA is still switched on => saves sensitivity data.

Example for implementation with standard connectivity (plus switching):

- 1. Insert a bridge between connection points of yellow wire and brown wire (plus).
- 2. Ensure that the entire monitoring range is uninterrupted.
- 3. Turn on supply voltages.
- 4. Remove bridge.



Recommendations:

The calibration is important for proper functionality of the light curtain. Rerun the calibration after each change on the light curtain.

For an error-free calibration the monitoring range must be free of obstacles and both LEDs on the receiver must light up.

Flashing codes during the calibration cycle

One LED flashes	Defective beams	
LEDs flash in-phase	Differences too big or not yet calibrated. Verify alignment of bars as well as monitoring range.	
LEDs flash out-phase	Error during Selftest	

LED Indicators / Error Diagnosis

When the light curtain detects a failure, the warning output is enabled and the LED displays one of the following error codes. As soon as the failure is resolved, the output becomes inactive again.

Receiver bar

LED1	LED2	Operating mode	Monitoring area
off	off	off	unknown
on	on	operational	free
on	off	operational	beam interrupted
flashing	on	simple error	free
flashing	off	simple error	beam interrupted
Double	Off	Configuration error	unknown
flashing			
flashing	flashing	fatal error A	unknown
	(in phase)		
flashing	flashing	fatal error B	unknown
	(out of phase)		

Simple error:

Light curtain continues to run with constriction, for example, beam blanked or contamination alarm.

Fatal error:

Light curtain no longer operational.


Transmitter bar

LED	Operating mode
off	off
on	operational
flashing	error




Interfaces / Outputs

Transmitter



M8 connector

View towards connector pins



Installation / Initial Operation

- Pay attention to the installation rules (see mounting instructions for light curtain bar pairs).
- Avoid optical sensors from mutually affecting each other, even through reflection, because this can lead to malfunction.
- Maximal 1.5 secounds after power up the light curtain is operating.
- Insulate unused wires.
- Disconnect the connections during insulation measurements.
- Execute a calibration cycle.



Conformity



The light curtain version LA is **C** compliant and meets all the requirements of the following standards:

- EN 61000-6-3:2001.
- EN 61000-6-1:2001.



The light curtains are not certified safety lights curtains compliant with EN 61496. They are not safety components in the context of EU Machine Guideline 89/392/EEC with 93/44/EMW addition. Appendix 4.

Therefore, they must not be used so as not to endanger individuals.

Technical Data

Light curtain housing Naturally anodised aluminium, plastic front panel, dark

(Do not use any cleaning agents containing solvents!) Connection

Securely attached lines 4 m long, precut with wire end

ferrules

Transmitter 2-core round cable, \varnothing about 4,9 mm (PVC) Receiver 4-core round cable, \emptyset about 4,9 mm (PVC)

Operating voltage 24 V DC (-15%..+20%) with max. ripple 5%, protected

against polarity reversal,

use polarised earthed power supply!

Power consumption approx. 8 W (total)

Short-circuit-proof semiconductor outputs Outputs

PNP (or NPN) switched current max. 200 mA

Operating temperature -10°C to 45 °C

Range² ~ 0.7 ... 4 m (calibration necessary)

default setting: 4m

~ 0.2 ... 1 m (calibration necessary) Reduced range

1 ms cycle time per beam plus base time (~4 ms) Response time

Maximum number of 128 logical beams

beams


² With standard profile. Range with other profile types see techn. Information light grid bar pairs.




PC-Interface

The PC Interface connects to the serial port of a PC. Use the Software DUO-Konf for configuration of a light curtain pair.





Minus switching light curtain





Ordering Key and Example

Key:


Light curtain bar pair Consisting of receiver and transmitter bar			
Туре	Beam Number / Beam Separation	Mechanical	Options
"LA"	Choose from beam seperation between 5mm and 112 mm.	Choose from 4 shapes and 8 mounting options	ColorCable lengthConnectivity optionFront cover

For details regarding the specific ordering codes refer to detailed light curtain bar document.

Example

LA16/112-2000A	Light curtain bar pair with integrated controler unit (24 Vdc, PNP) 16 beams Beam spacing of approx. 112 mm Bar length 2000 mm, bar cross-section 12x24 mm, Aluminium naturally anodized 4 bolts on top, cone on the bottom Protection class IP54 Parameterisation: standard*)
LA24/12,5-510I	Light curtain bar pair with integrated controler unit (24 Vdc, PNP) 24 beams Beam spacing of approx. 12,5 mm Bar length 510 mm, bar cross-section 12x24 mm, Aluminium naturally anodized 2 M4x10 threaded stud bolts spaced 400 mm apart Protection class IP54 Parameterisation: dark diagonal beams

^{*)} Default values can be found in the configuration table. Please mention different parameterisations in your purchase order.





Accessories


LCPower/2 FP-110-00001 Power Supply(24Vdc) for types LC/LA/LT

- 230/110 Vac
- plastic housing
- Protection class IP65
- Relais

LCPower/2-SR Power Supply(24Vdc) for types LC/LA/LT

FP-110-00002 - 2xRelaisoutput

- connections via PG 9
- internal connection via terminal block
- plastic housing
- buzzer



Programming interface for plus- and minus switching systems

Including connection wires

DUO Konf-Software for Download: FP-20-13538 http://www.duometric.com/Dokus/LA/

